

ECO 120 / 121 Waterproof alarm thermometer for exchangeable probes BNC / permanent probes

- Modern and functional housing
- Quick and precise measurement
- Waterproof (IP65 / IP67)
- Available in two variations:
 - With BNC connection for exchangeable probes (ECO 120)
 - With permanently connected probe (ECO 121)
- Probe and cable permanently resistant to temperatures up to 230°C (2 hours up to 250 °C)
- Waterproof (IP65 / IP67)
- 3-line display / overhead display at keypress
- Backlight
- Alarm function
- Adjustable
- Robust, long battery life
- Hold-function to freeze measured values
- Min/Max-function for minimum and maximum recorded measured values



DESCRIPTION

The primary focus in the development of the ECO-line was place on the essential functions of the measurement technology. Pure measurement with a focus on precision, speed and reliability packaged in a compact housing distinguish an impressive price/performance ratio, Made in Germany.

The handheld measuring devices also impress with their ergonomic design, dust and water-protected design according to IP 65/67 and the illuminated display.

The compact thermometer is available with a practical BNC connection for interchangeable sensors or as a complete device including sensor with maximum overall precision. The device redefines our entry-level measurement class – test protocol included.

The matching sensors can be used at temperatures of up to 250 °C (incl. handle and cable) and are distinguished by their compact design and small tube diameter. Integrated: High-quality Pt1000 sensors.



ECO 120 front: BNC for exchangeable probes

Family Datasheet

ECO 120 / 121 Waterproof alarm thermometer

for exchangeable probes BNC / permanent probes

Display

Thanks to the backlight, the three-line LCD display offers ergonomic wide-angle visibility - by day and by night.

The HOLD function enables the display values to be frozen.

Power supply

2 powerful AA batteries, the energy-saving design and the configurable automatic switch-off function ensure long operation.

Configurable LCD backlight for further energy saving options.

TECHNICAL DATA

Measurement specifications

	ECO 120	ECO 121 -3 / -I3 / -I1.5
Inputs	BNC socket for exchangeable probes, see accessories / exchangeable probes	fixed Pt1000 probe
Measuring range	Temperature -200.0 ... +450.0 °C (-328.0...+842.0 °F) observe permissible range of the probe!	Temperature -70.0 ... +250.0 °C (-94.0...+482.0 °F)
Accuracy (nominal temperature)	-20 ... +100 °C: $\pm 0.1 \text{ K} \pm 1 \text{ digit}$ otherwise with 0.1 % of value $\pm 2 \text{ digits}$ plus probe inaccuracy acc. to class	-20 ... +100 °C: $\pm 0.1 \text{ K} \pm 1 \text{ digit}$ -70 ... +250 °C: $\pm 0.2 \text{ \% of value} \pm 2 \text{ digit}$
Max. cable length	3 m	

General specifications

Display	3-line with battery status indicator, Backlight, protected by shatterproof screen, overhead display at keypress	
Power supply	2 x AA Alkaline batteries (included)	
Power consumption	ca. 0.4 mA, ca. 2 mA with backlight	
Battery life	ca 5000 h typ. Continuous operation	
Automatic Power-Off	Yes, configurable by the user	
Operating conditions instrument	-20 to 50 °C; 0 to 95 % r.h. (non-condensing)	
Probe variant		3: Immersion 100 mm, Ø 3 mm I3: Insertion 100 mm, Ø 3 mm I1.5: thin immersion 100 mm, Ø 1,5 mm
Probe cable and handle		Silicon, short time 250°C, permanent 230°C
Storage temperature	-20...70 °C (without batteries)	
Protection class	IP65 / 67 (only with waterproof probes in the connected state for devices with BNC connection)	
Dimensions	108 x 54 x 28 mm (H x W x D)	
Weight	approx. 130 g (without probe)	
Housing	Impact resistant ABS, Polyester (front panel)	

ECO 120 / 121 Waterproof alarm thermometer

for exchangeable probes BNC / permanent probes

ORDERING CODES

ECO120	
Waterproof alarm thermometer for exchangeable probes BNC (formerly G 1700)	
1	Set-Option - Device in carton box, test protocol, batteries, manual -GKK1000 Device in case GKK 1000, test protocol, batteries, manual -WPT2A Device in case GKK 1000, immersion probe GF1T-T3-AA-BNC, factory calibration WPT2A 0 / 70 °C not DAkkS accredited -WPT2B Device in case GKK 1000, immersion probe GF1T-T3-AA-BNC, factory calibration WPT2A 0 / 37 °C not DAkkS accredited -WPT3 Device in case GKK 1000, immersion probe GF1T-T3-AA-BNC, factory calibration WPT3 -20 / 0 / 70 °C not DAkkS accredited
ECO121-3	
Waterproof alarm thermometer with immersion probe (formerly G 1710)	
1	Probe (permanently connected) - With immersion probe GF 1TK-T3, 100 mm, Ø3 mm, handle and cable short time 250°C, permanent 230°C
2	Set-Option - Device in carton box, test protocol, batteries, manual -GKK1000 Device in case GKK 1000, test protocol, batteries, manual -WPT2A incl. WPT2A, factory calibration, test points: 0 °C / 70 °C + GKK 1000, not DAkkS accredited -WPT2B incl. WPT2B, factory calibration, test points: 0 °C / 37 °C + GKK 1000, not DAkkS accredited -WPT3 incl. WPT3, factory calibration, test points: -20 °C, 0 °C, 70 °C + GKK 1000, not DAkkS accredited -MB4 Measuring range -200 ... +250 °C (Standard: -70 ... +250 °C)
ECO121-I3	
Waterproof alarm thermometer with insertion probe (formerly G 1720)	
1	Probe (permanently connected) - With robust insertion probe, 100 mm, Ø3 mm, handle and cable short time 250°C, permanent 230°C
2	Set-Option - Device in carton box, test protocol, batteries, manual -GKK1000 Device in case GKK 1000, test protocol, batteries, manual -WPT2A incl. WPT2A, factory calibration, test points: 0 °C / 70 °C + GKK 1000, not DAkkS accredited -WPT2B incl. WPT2B, factory calibration, test points: 0 °C / 37 °C + GKK 1000, not DAkkS accredited -WPT3 incl. WPT3, factory calibration, test points: -20 °C, 0 °C, 70 °C + GKK 1000, not DAkkS accredited -MB4 Measuring range -200 ... +250 °C (Standard: -70 ... +250 °C)

ECO 120 / 121 Waterproof alarm thermometer

for exchangeable probes BNC / permanent probes

ECO121-I1.5	
Waterproof alarm thermometer with insertion probe (formerly G 1730)	
1	Probe (permanently connected) - With fast penetration probe 100 mm, Ø1.5 mm, handle and cable short time 250°C, permanent 230°C
2	Set-Option - Device in carton box, test protocol, batteries, manual -GKK1000 Device in case GKK 1000, test protocol, batteries, manual -WPT2A incl. WPT2A, factory calibration, test points: 0 °C / 70 °C + GKK 1000, not DAkkS accredited -WPT2B incl. WPT2B, factory calibration, test points: 0 °C / 37 °C + GKK 1000, not DAkkS accredited -WPT3 incl. WPT3, factory calibration, test points: -20 °C, 0 °C, 70 °C + GKK 1000, not DAkkS accredited

STANDARD ARTICLES



ECO 120

Device in carton box, test protocol, batteries

Art no.: 486749



ECO 121-3

Device in carton box, test protocol, batteries, manual with immersion probe 100 mm, Ø 3 mm, Pt1000 2-wire fixed connection, V4A, 1m cable

Art no.: 486750



ECO 121-I3

Device in carton box, test protocol, batteries, manual with durable insertion probe 100 mm, Ø 3 mm, Pt1000 2-wire fixed connection, V4A, 1m cable

Art no.: 486751



ECO 121-I1.5

Device in carton box, test protocol, batteries, manual with extra-thin insertion probe 100 mm, Ø 1.5 mm, Pt1000 2-wire fixed connection, V4A, 1 m cable

Art no.: 486757



Technical specifications probe

Probe reaction time (T90)	Ø 3 mm: Water 0.4 m/s < 3 s
	Ø 1.5 mm: Water 0.4 m/s < 2 s

ECO 120 / 121 Waterproof alarm thermometer

for exchangeable probes BNC / permanent probes

ACCESSORIES

Spare parts:

GB-AA-2 Spare batteries 2x AA **Art no.: 600704**

Exchangeable probes for ECO 120:

GF1T-T3-B-BNC Pt1000 immersion probe class B, 100 mm, Ø 3 mm, with BNC connector
(like ECO 121-3) **Art no.: 609549**

GF1T-T3-AA-BNC Pt1000 immersion probe class AA, 100 mm, Ø 3 mm, with BNC connector
Art no.: 609550



GF1T-E3-B-BNC Pt1000 insertion probe class B, 100 mm, Ø 3 mm, with BNC connector
(like ECO 121-I3) **Art no.: 609639**



GF1T-E1.5-B-BNC Pt1000 insertion probe class B, 100 mm, Ø 1.5 mm, with BNC connector
(like ECO 121-I1.5) **Art no.: 609645**



Technical specifications exchangeable probes

Class B	±0.3°C @0°C
Class AA	±0.1°C @0°C
Measuring range	-70 ... 250 °C
Cable and handle	Silicon, -50...230°C, short time 250°C, cable length ca. 1m

Additional accessories:

G1000-Cover ECO-line/G 1000 rubber protection cover, incl. 2 neodymium magnets **Art no.: 483958**

ST-G1000 Protection bag with belt clip **Art no.: 611373**

GCLIP1000 Metal belt clip self-adhesive **Art no.: 475820**

G1000-BASE ECO-line/G 1000 combined table base / wall suspension **Art no.: 481885**

GKK1000 Carrying case **Art no.: 611603**

For further articles, please visit Senseca website.